


Product Manual Burns T65 (PR 6335D2A) 2-wire HART transmitter

















Burns FORM - 161222-E

No. 6335V111-UK

From serial no.: 150951186



2-wire HART transmitter Burns T65 (PR 6335D2A)

Table of contents

Technical characteristics	2
Mounting / installation	4
Applications	4
Order	5
Electrical specifications	
Connections	8
Block diagram	
Programming	Š
Connection of transmitters in multidrop mode	
ATEX Installation Drawing - 6335D	14
IECEx Installation Drawing - 6335D	18
CSA Installation Drawing - 6335D	
FM Installation Drawing - 6335D	22
Document history	24

2-wire HART transmitter Burns T65 (PR 6335D2A)

- RTD, TC, Ohm, or mV input
- Extremely high measurement accuracy
- HART communication
- Galvanic isolation
- 1- or 2-channel version

Application

- Linearized temperature measurement with Pt100...Pt1000, Ni100...Ni1000, TC or sensor.
- Difference or average temperature measurement of 2 resistance or TC sensors.
- Conversion of linear resistance variation to a standard analog current signal, for instance from valves or Ohmic level sensors.
- Amplification of a bipolar mV signal to a standard 4...20 mA current signal.
- Connection of up to 15 channels to a digital 2-wire signal with HART communication.


Technical characteristics

- Within a few seconds the user can program PR6335 to measure temperatures within all ranges defined by the norms.
- The RTD and resistance inputs have cable compensation for 2-, 3- and 4-wire connection.
- The 6335 has been designed according to strict safety requirements and is thus suitable for application in SIL 2 installations.
- A limit can be programmed on the output signal.
- Continuous check of vital stored data for safety reasons.
- Sensor error detection according to the guidelines in NAMUR NE 89.

Mounting / installation

- Mounted vertically or horizontally on a DIN rail. Using the 2-channel version up to 84 channels per metre can be mounted.
- The 6335D can be mounted in zone 0, 1, 2 and zone 20, 21, 22 including M1 / Class I/II/ III, Division 1, Groups A, B, C, D.

Applications



Model T65:

- Rail Mount Transmitter
- RTD & Thermocouple Capable
- HART® 5 Communication
- · Hazardous Location Approvals:
 - ATEX, IECEx, FM, CSA

Electrical specifications

Environmental conditions:

Mechanical specifications:

Common specifications:

Supply voltage, DC

Accuracy, the greater of general and basic values:

General values			
Input type	Absolute accuracy	Temperature coefficient	
All	≤ ±0.05% of span	≤ ±0.005% of span / °C	

Basic values			
Input type	Basic accuracy	Temperature coefficient	
Pt100 / Pt1000	≤ ±0.1°C	≤ ±0.005°C/°C	
Ni100	≤ ±0.2°C	≤ ±0.005°C/°C	
Lin. R	≤ ±0.1 Ω	≤ ±5 mW / °C	
Volt	≤ ±10 µV	≤ ±0.5 µV / °C	
TC type: E, J, K, L, N, T, U	≤ ±0.5°C	≤ ±0.025°C / °C	
TC type: B, R, S, W3, W5	≤ ±1°C	≤ ±0.1°C / °C	

EMC - immunity influence	
Extended EMC immunity:	
NAMUR NE 21, A criterion, burst < ±1% of span	

Electrical specifications, inputs:

RTD and linear resistance input:

RTD	Min.	Max.	Min.	
type	value	value	span	Standard
Pt100	-200°C	+850°C	10°C	IEC 60751
Ni100	-60°C	+250°C	10°C	DIN 43760
Lin. R	0 Ω	7000 Ω	25 Ω	

Sensor error detection Yes

TC inputs:

	Min.	Max.	Min.	
Type	temperature	temperature	span	Standard
В	+400°C	+1820°C	100°C	IEC584
E	-100°C	+1000°C	50°C	IEC584
l j	-100°C	+1200°C	50°C	IEC584
K	-180°C	+1372°C	50°C	IEC584
L	-100°C	+900°C	50°C	DIN 43710
N	-180°C	+1300°C	50°C	IEC584
R	-50°C	+1760°C	100°C	IEC584
S	-50°C	+1760°C	100°C	IEC584
T	-200°C	+400°C	50°C	IEC584
U	-200°C	+600°C	50°C	DIN 43710
W3	0°C	+2300°C	100°C	ASTM E988-90
W5	0°	+2300°C	100°C	ASTM E988-90
Cold junction companyation				

Sensor error detection Yes

Sensor error current:

Voltage inputs:

Output:

Current output:

 Signal range.
 4...20 mA

 Min. signal range.
 16 mA

 Updating time
 440 ms

Sensor error detection:

(shorted sensor error detection is ignored at TC and mV input)

Of span = Of the presently selected range

Approvals:

Ex / I.S.:


Functionel safety:

Hardware assessed for use in SIL applications


FMEDA-report - www.prelectronics.com

Connections


Inputs:



Inputs:



Block diagram



Programming

6335 can be configured in the following 3 ways:


- 1. With PR electronics A/S' communications interface Loop Link and PReset PC configuration software.
- 2. With a HART modem and PReset PC configuration software.
- 3. With a HART communicator with PR electronics A/S' DDL driver.

1: Loop Link

For programming please refer to the drawing below and the help functions in PReset.


When communicating with non-installed devices, connectors 11, 12, 13, 14 (channel 1) and 21, 22, 23, 24 (channel 2) can be dismantled in the safe area to connect the terminals of the communications interface to the pins.

Loop Link is not approved for communication with devices installed in hazardous (Ex) area.




2: HART modem

For programming please refer to the drawing below and the help functions in PReset.




3: HART communicator

For programming please refer to the drawing below. To get access to productspecific commands, the HART communicator must be loaded with the PR electronics A/S DDL driver. This can be ordered either at the HART Communication Foundation or PR electronics A/S.



Connection of transmitters in multidrop mode

The HART communicator or a PC modem can be connected accross AB or BC.



- The outputs of max. 15 transmitters can be conected in parallel for a digital HART communication on 2-wires.
- Before it is connected, each transmitter must be configured with a unique number from 1 to 15. If 2 transmitters are configured with the same number, both will be excluded. The transmitters must be programmed for multidrop mode (with a fixed output signal of 4 mA). Maximum current in the loop is therefore 60 mA.
- The communication is either by means of a HART communicator or a HART modem.
- The PReset PC configuration software can configure the individual transmitter for multidrop mode and provide it with a unique polling address.



WWW.PRELECTRONICS.COM

ATEX Installation drawing



For safe installation of 6335D or 6337D the following must be observed. The module shall only be Installed by qualified personnel who are familiar with the national and international laws, directives and standards that apply to this area.

Year of manufacture can be taken from the first two digits in the serial number.


ATEX Certificate KEMA 09ATEX 0148 X

Marking

 $\langle \epsilon_{x} \rangle$

II 1G Ex ia IIC T6..T4 Ga II 1D Ex ia IIIC Da I M 1 Ex ia I Ma

Standards EN60079-0:2012, EN60079-11:2012, EN60079-26:2007



Revision date: Version Revision 0Page: 2014-06-20 V4R0 1/2

Pi: 0.84 W Li: 10μH Ci: 1.0nF



WWW.PRELECTRONICS.COM

General installation instructions

To avoid risk of ignition during installation and maintenance appropriate safety measures against electrostatic discharge (ESD) are to be considered.

The sensor circuit is not infallibly galvanic isolated from the supply output circuit. However, the galvanic isolation between the circuits is capable of withstanding a test voltage of 500Vac during 1 minute.

For installation in a potentially explosive gas atmosphere the following instructions apply:

To avoid risk of ignition due to electrostatic discharge (ESD) the transmitter shall be mounted in an enclosure providing a degree of protection of at least IP20 according to EN/IFC 60529

Ambient temperature range:

T4: $-40 \le Ta \le 85^{\circ}C$ T5: $-40 \le Ta \le 60^{\circ}C$ T6: $-40 \le Ta \le 40^{\circ}C$

For installation in a potentially explosive dust atmosphere, the following instructions apply:

The transmitter shall be mounted in a metal enclosure or equivalent that is providing a degree of protection of at least IP6X according to EN/IEC 60529 that is suitable for the application and correctly installed. Cable entries and blanking elements shall be used that are suitable for the application and correctly installed. The surface temperature of the enclosure is equal to the ambient temperature +20K for a dust layer with a maximum thickness of 5 mm. Ambient temperature range:

T4: -40 ≤ Ta ≤ 85°C

For installation in a potentially explosive atmosphere in mines, the following instructions apply: The transmitter shall be mounted in an enclosure providing a degree of protection of at least IP6X according to EN/IEC 60529. Cable entries and blanking elements shall be used that are suitable for the application and correctly installed.

Ambient temperature range:

T4: -40 ≤ Ta ≤ 85°C

Revision date: Version Revision 0Page: 2014-06-20 V4R0 2/2



WWW.PRELECTRONICS.COM

IECEx Installation drawing



For safe installation of 6335D or 6337D the following must be observed. The module shall only be installed by qualified personnel who are familiar with the national and international laws, directives and standards that apply to this area.


Year of manufacture can be taken from the first two digits in the serial number.

IECEx Certificate IECEx KEM.10.0084X

Marking Ex ia IIC T6..T4 Ga

Ex ia IIIC Da Ex ia I Ma

Standards: IEC60079-0:2011, IEC60079-11: 2011, IEC60079-26:2006



Revision date: Version Revision Page: 2014-06-20 V4R0 1/2



WWW.PRELECTRONICS.COM

General installation instructions

To avoid risk of ignition during installation and maintenance appropriate safety measures against electrostatic discharge (ESD) are to be considered.

The sensor circuit is not infallibly galvanic isolated from the supply output circuit. However, the galvanic isolation between the circuits is capable of withstanding a test voltage of 500Vac during 1 minute.

For installation in a potentially explosive gas atmosphere the following instructions apply:

To avoid risk of ignition due to electrostatic discharge (ESD) the transmitter shall be mounted in an enclosure providing a degree of protection of at least IP20 according to EN/IEC 60529.

Ambient temperature range:

T4: -40 ≤ Ta ≤ 85°C T5: -40 ≤ Ta ≤ 60°C T6: -40 ≤ Ta ≤ 40°C

For installation in a potentially explosive dust atmosphere, the following instructions apply:

The transmitter shall be mounted in a metal enclosure or equivalent that is providing a degree of protection of at least IP6X according to EN/IEC 60529 that is suitable for the application and correctly installed. Cable entries and blanking elements shall be used that are suitable for the application and correctly installed. The surface temperature of the enclosure is equal to the ambient temperature +20K for a dust layer with a maximum thickness of 5 mm. Ambient temperature range:

T4: -40 ≤ Ta ≤ 85°C

For installation in a potentially explosive atmosphere in mines, the following instructions apply: The transmitter shall be mounted in an enclosure providing a degree of protection of at least IP6X according to EN/IEC 60529. Cable entries and blanking elements shall be used that are suitable for the application and correctly installed.

Ambient temperature range:

T4: -40 ≤ Ta ≤ 85°C

Revision date: Version Revision Page: 2014-06-20 V4R0 2/2




CSA Installation drawing 6335QC02

LERBAKKEN 10, 8410 RØNDE DENMARK.

WWW.PRELECTRONICS.COM

Hazardous (Classified) Location IS,Class I, Division 1, Group A,B,C,D T4..T6 Ex ia IIC T4..T6 Ga Class I, Zone 0, AEx ia IIC T4..T6 Ga

Non Hazardous Location



Installation notes.

The Transmitter must be installed in a suitable enclosure to meet installation codes stipulated in The Canadian Electrical Code (CEC).

Substitution of components may impair intrinsic safety.




CSA Installation drawing 6335QC02

LERBAKKEN 10, 8410 RØNDE DENMARK.

WWW.PRELECTRONICS.COM

Hazardous (Classified) Location IS,Class I, Division 1, Group A,B,C,D T4..T6 Ex ia IIC T4..T6 Ga Class I, Zone 0, AEx ia IIC T4..T6 Ga Non Hazardous Location



Installation notes.

The Transmitter must be installed in a suitable enclosure to meet installation codes stipulated in The Canadian Electrical Code (CEC).

Channel 1 and Channel 2 are separate channels and therefore separate shielded cables shall be used for each channel.

Substitution of components may impair intrinsic safety.

21




FM Installation drawing 6335QF01

LERBAKKEN 10, 8410 RØNDE DENMARK.

WWW.PRELECTRONICS.COM

Hazardous (Classified) Location Class I, Division 1, Group A,B,C,D T4..T6 Class I, Zone 0, AEx ia IIC T4..T6

Non Hazardous Location



Terminal: 11,12,13,14 and 21,22,23,24

Ui: 30 VDC Ii: 120 mA Pi: 0.84 W Li: 10 μH Ci: 1.0 nF

Installation notes

For installation in Class I the Transmitter must be installed in a suitable enclosure to meet installation codes stipulated in The National Electrical Code (ANSI-NFPA 70).

Equipment that is FM-approved for intrinsic safety may be connected to barriers based on the Entity Concept. This concept permits interconnection of approved transmitters, meters and other devices in combinations, which have not been specifically examined by FM, provided that the agency's criteria are met. The combination is then intrinsically safe, if the entity concept is acceptable to the authority having jurisdiction over the installation.

The entity concept criteria are as follows: The intrinsically safe devices, other than barriers, must not be a source of power. The maximum voltage $Ui(V_{MAX})$ and current $Ii(I_{MAX})$, and maximum power Pi(Pmax), which the device can receive and remain intrinsically safe, must be equal to or greater than the voltage (Uo or V_{OC} or V_t) and current (Io or I_{SC} or I_t) and the power Po which can be delivered by the barrier. The sum of the maximum unprotected capacitance (C_i) for each intrinsically device and the interconnecting wiring must be less than the capacitance (C_a) which can be safely connected to the barrier. The sum of the maximum unprotected inductance (L_i) for each intrinsically device and the interconnecting wiring must be less than the inductance (L_a) which can be safely connected to the barrier. The entity parameters Uo, V_{OC} or V_t and Io, I_{SC} or I_t , and C_a and L_a for barriers are provided by the barrier manufacturer.


Revision date: Version Revision Page: 2014-09-16 V6R0 1/2

FM Installation drawing 6335QF01

LERBAKKEN 10, 8410 RØNDE DENMARK.

WWW.PRELECTRONICS.COM

Hazardous (Classified) Location Class I, Division 2, Group A,B,C,D T4..T6 Class I, Zone 2, IIC T4..T6



Installation notes

The Transmitter must be installed in a suitable enclosure to meet installation codes stipulated in The National Electrical Code (ANSI-NFPA 70).

To assure a Non-Incendive system the transmitter and associated apparatus must be wired in accordance with the associated apparatus manufacturers field wiring instructions and the circuit diagram shown above.

23

Document history

The following list provides notes concerning revisions of this document.

Rev. ID	Date	Notes
111	15/50	ATEX & IECEx M1 approval added

Distributed By: Burns Engineering 10201 Bren Road East Minnetonka MN 55343



For assistance:

Phone (Local): 952-935-4400 Phone (Toll Free): 800-328-3871

FAX: 952-935-8782

Email: info@BurnsEngineering.com
Visit: www.BurnsEngineering.com